



OWNER'S MANUAL

Thundercat

YZF600R

4TV-28199-E6

Welcome to the Yamaha world of motorcycling!

As the owner of a YZF600R, you are benefiting from Yamaha's vast experience and newest technology regarding the design and manufacture of high-quality products, which have earned Yamaha a reputation for dependability.

Please take the time to read this manual thoroughly, so as to enjoy all advantages of your YZF600R. The owner's manual does not only instruct you in how to operate, inspect and maintain your motorcycle, but also in how to safeguard yourself and others from trouble and injury.

In addition, the many tips given in this manual will help keep your motorcycle in the best possible condition. If you have any further questions, do not hesitate to contact your Yamaha dealer.

The Yamaha team wishes you many safe and pleasant rides. So, remember to put safety first!

IMPORTANT MANUAL INFORMATION

EAU00005

Particularly important information is distinguished in this manual by the following notations:



The Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**



Failure to follow **WARNING** instructions could result in severe injury or death to the motorcycle operator, a bystander, or a person inspecting or repairing the motorcycle.

CAUTION:

A **CAUTION** indicates special precautions that must be taken to avoid damage to the motorcycle.

NOTE:

A **NOTE** provides key information to make procedures easier or clearer.

NOTE:

- This manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.
 - Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your motorcycle and this manual. If you have any questions concerning this manual, please consult your Yamaha dealer.
-

IMPORTANT MANUAL INFORMATION

EW000002

 **WARNING**

PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS MOTORCYCLE.

IMPORTANT MANUAL INFORMATION

EAU04229

**YZF600R
OWNER'S MANUAL
© 2001 by Yamaha Motor Co., Ltd.
1st edition, May 2001
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.**

1 GIVE SAFETY THE RIGHT OF WAY	1
2 DESCRIPTION	2
3 INSTRUMENT AND CONTROL FUNCTIONS	3
4 PRE-OPERATION CHECKS	4
5 OPERATION AND IMPORTANT RIDING POINTS	5
6 PERIODIC MAINTENANCE AND MINOR REPAIR	6
7 MOTORCYCLE CARE AND STORAGE	7
8 SPECIFICATIONS	8
9 CONSUMER INFORMATION	9
INDEX	



GIVE SAFETY THE RIGHT OF WAY

GIVE SAFETY THE RIGHT OF WAY 1-1



Motorcycles are fascinating vehicles, which can give you an unsurpassed feeling of power and freedom. However, they also impose certain limits, which you must accept; even the best motorcycle does not ignore the laws of physics.


Regular care and maintenance are essential for preserving value and operating condition of your motorcycle. Moreover, what is true for the motorcycle is also true for the rider: good performance depends on being in good shape. Riding under the influence of medication, drugs and alcohol is, of course, out of the question. Motorcycle riders—more than car drivers—must always be at their mental and physical best. Under the influence of even small amounts of alcohol, there is a tendency to take dangerous risks.

Protective clothing is as essential for the motorcycle rider as seat belts are for car drivers and passengers. Always wear a complete motorcycle suit (whether made of leather or tear-resistant synthetic materials with protectors), sturdy boots, motorcycle gloves and a properly fitting helmet. Optimum protective wear, however, should not encourage carelessness. Although full-coverage helmets and suits, in particular, create an illusion of total safety and protection, motorcyclists will always be vulnerable. Riders who lack critical self-control run the risk of going too fast and are apt to take chances. This is even more dangerous in wet weather. The good motorcyclist rides safely, predictably and defensively—avoiding all dangers, including those caused by others.

Enjoy your ride!


Left view	2-1
Right view.....	2-2
Controls and instruments	2-3

Left view



- | | |
|--|-------------|
| 1. Air intake duct | (page 6-19) |
| 2. Fuel tank | (page 3-8) |
| 3. Shock absorber assembly spring preload adjusting ring | (page 3-15) |
| 4. Shock absorber assembly rebound damping force adjusting knob | (page 3-15) |
| 5. Shock absorber assembly compression damping force adjusting screw | (page 3-16) |
| 6. Storage compartment | (page 3-12) |
| 7. Helmet holder | (page 3-12) |
| 8. Grab bar | |
| 9. Shift pedal | (page 3-7) |
| 10. Radiator | (page 6-15) |

Right view




- | | |
|--|-------------|
| 11. Luggage strap holders | (page 3-18) |
| 12. Rear brake fluid level check window | (page 6-28) |
| 13. Coolant reservoir | (page 6-13) |
| 14. Front fork spring preload adjusting bolt | (page 3-13) |
| 15. Front fork rebound damping force adjusting screw | (page 3-14) |
| 16. Radiator cap | (page 6-15) |
| 17. Front fork compression damping force adjusting screw | (page 3-14) |
| 18. Engine oil level check window | (page 6-10) |
| 19. Brake pedal | (page 3-8) |
| 20. Engine oil filler cap | (page 6-10) |

DESCRIPTION

Controls and instruments


2



- | | |
|-------------------------------|-------------|
| 1. Clutch lever | (page 3-7) |
| 2. Left handlebar switches | (page 3-5) |
| 3. Starter (choke) lever | (page 3-11) |
| 4. Speedometer unit | (page 3-3) |
| 5. Tachometer | (page 3-4) |
| 6. Coolant temperature gauge | (page 3-5) |
| 7. Right handlebar switches | (page 3-6) |
| 8. Brake lever | (page 3-7) |
| 9. Throttle grip | (page 6-20) |
| 10. Main switch/steering lock | (page 3-1) |

INSTRUMENT AND CONTROL FUNCTIONS

Main switch/steering lock	3-1	Fuel	3-9
Indicator and warning lights	3-2	Fuel tank breather hose (for Germany only)	3-10
Speedometer unit	3-3	Starter (choke) lever	3-11
Tachometer	3-4	Seat	3-11
Self-diagnosis device	3-4	Helmet holder	3-12
Coolant temperature gauge	3-5	Storage compartment	3-12
Anti-theft alarm (optional)	3-5	Adjusting the front fork	3-13
Handlebar switches	3-5	Adjusting the shock absorber assembly	3-15
Clutch lever	3-7	Matching the front and rear suspension settings	3-17
Shift pedal	3-7	Luggage strap holders	3-18
Brake lever	3-7	Sidestand	3-18
Brake pedal	3-8	Ignition circuit cut-off system	3-19
Fuel tank cap	3-8		



EAU00029

Main switch/steering lock

The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

ON


All electrical systems are supplied with power, and the engine can be started. The key cannot be removed.

EAU00036

OFF

All electrical systems are off. The key can be removed.

EAU00038



EAU00040

LOCK


The steering is locked, and all electrical systems are off. The key can be removed.

To lock the steering

1. Turn the handlebars all the way to the left.
2. Push the key in from the "OFF" position, and then turn it to "LOCK" while still pushing it.
3. Remove the key.

To unlock the steering

Push the key in, and then turn it to "OFF" while still pushing it.



1. Push.
2. Turn.

EW000016

⚠ WARNING

Never turn the key to "OFF" or "LOCK" while the motorcycle is moving, otherwise the electrical systems will be switched off, which may result in loss of control or an accident. Make sure that the motorcycle is stopped before turning the key to "OFF" or "LOCK".

INSTRUMENT AND CONTROL FUNCTIONS

P⊆ (Parking)

EAU01590


The steering is locked, and the taillight and auxiliary light are on, but all other electrical systems are off. The key can be removed.






The steering must be locked before the key can be turned to “P⊆”.

ECA00043

CAUTION:

Do not use the parking position for an extended length of time, otherwise the battery may discharge.



1. Neutral indicator light “N”
2. Oil level warning light “”
3. Fuel level warning light “”
4. Turn signal indicator light “ ”
5. High beam indicator light “”

EAU03034

Indicator and warning lights

EAU00061

Neutral indicator light “N”


This indicator light comes on when the transmission is in the neutral position.

EAU03201

Oil level warning light “”

This warning light comes on when the engine oil level is low.

The electrical circuit of the warning light can be checked according to the following procedure.


1. Set the engine stop switch to “” and turn the key to “ON”.
2. Shift the transmission into the neutral position or pull the clutch lever.
3. Push the start switch. If the warning light does not come on while pushing the start switch, have a Yamaha dealer check the electrical circuit.






NOTE:

Even if the oil level is sufficient, the warning light may flicker when riding on a slope or during sudden acceleration or deceleration, but this is not a malfunction.

INSTRUMENT AND CONTROL FUNCTIONS

3




1. Neutral indicator light “N”
2. Oil level warning light “”
3. Fuel level warning light “”
4. Turn signal indicator light “ ”
5. High beam indicator light “”

EAU003509

Fuel level warning light “”

This warning light comes on when the fuel level drops below approximately 3.1 L. When this occurs, refuel as soon as possible.

The electrical circuit of the warning light can be checked according to the following procedure.

1. Set the engine stop switch to “” and turn the key to “ON”.
2. Shift the transmission into the neutral position or pull the clutch lever.

3. Push the start switch. If the warning light does not come on, have a Yamaha dealer check the electrical circuit.

NOTE:

This model is equipped with a self-diagnosis device for the fuel level warning light circuit. (See page 3-4 for an explanation of the self-diagnosis device.)

EAU00057


Turn signal indicator light “ ”

This indicator light flashes when the turn signal switch is pushed to the left or right.

EAU00063

High beam indicator light “”

This indicator light comes on when the high beam of the headlight is switched on.




1. Odometer
2. Tripmeter reset knob
3. Tripmeter

EAU00095

Speedometer unit

The speedometer unit is equipped with a speedometer, an odometer and a tripmeter. The speedometer shows riding speed. The odometer shows the total distance traveled. The tripmeter shows the distance traveled since it was last set to zero with the reset knob. The tripmeter can be used to estimate the distance that can be traveled with a full tank of fuel. This information will enable you to plan future fuel stops.

INSTRUMENT AND CONTROL FUNCTIONS



1. Tachometer
2. Tachometer red zone

Tachometer

The electric tachometer allows the rider to monitor the engine speed and keep it within the ideal power range.

CAUTION:

Do not operate the engine in the tachometer red zone.

Red zone: 13,200 r/min and above

EAU00101


EC000003

Self-diagnosis device

This model is equipped with a self-diagnosis device for the following electrical circuits:

- throttle position sensor
- fuel level warning light

If any of those circuits are defective, the tachometer will repeatedly display the following error code:



Use the table below to identify the faulty electrical circuit.

Specific r/min	Faulty electrical circuit
3,000 r/min	Throttle position sensor
8,000 r/min	Fuel level warning light

EAU00105

If the tachometer displays such an error code, note the circuit-specific number of r/min, and then have a Yamaha dealer check the motorcycle.


EC000004

CAUTION:

When the tachometer displays an error code, the motorcycle should be checked as soon as possible in order to avoid engine damage.

INSTRUMENT AND CONTROL FUNCTIONS

3



1. Coolant temperature gauge
2. Coolant temperature gauge red zone

EAU01652

Coolant temperature gauge

With the key in the “ON” position, the coolant temperature gauge indicates the temperature of the coolant. The coolant temperature varies with changes in the weather and engine load. If the needle reaches or enters the red zone, stop the motorcycle and let the engine cool. (See page 6-45 for further instructions.)

EC000002


CAUTION:

Do not operate the engine if it is overheated.

EAU00109

Anti-theft alarm (optional)

This motorcycle can be equipped with an optional anti-theft alarm by a Yamaha dealer. Contact a Yamaha dealer for more information.



1. Pass switch “PASS”
2. Dimmer switch “ \equiv / \equiv ”
3. Turn signal switch “ \leftarrow / \rightarrow ”
4. Horn switch “ HORN ”

EAU00118

Handlebar switches

EAU00120

Pass switch “PASS”

Press this switch to flash the headlight.

EAU03888



Dimmer switch “ \equiv / \equiv ”

Set this switch to “ \equiv ” for the high beam and to “ \equiv ” for the low beam.

INSTRUMENT AND CONTROL FUNCTIONS

Turn signal switch “/”


EAU03889




To signal a right-hand turn, push this switch to “”. To signal a left-hand turn, push this switch to “”. When released, the switch returns to the center position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

Horn switch “”

EAU00129



Press this switch to sound the horn.



1. Engine stop switch “/”
2. Light switch “/”
3. Start switch “”




Engine stop switch “/”

EAU03890

Set this switch to “” before starting the engine. Set this switch to “” to stop the engine in case of an emergency, such as when the motorcycle overturns or when the throttle cable is stuck.

Light switch “/”

EAU03898

Set this switch to “/” to turn on the auxiliary light, meter lighting and taillight. Set the switch to “” to turn on the headlight also. Set the switch to “” to turn off all the lights.

Start switch “”

EAU00143

Push this switch to crank the engine with the starter.


EC000005

CAUTION:

See page 5-1 for starting instructions prior to starting the engine.

INSTRUMENT AND CONTROL FUNCTIONS

3




1. Clutch lever

EAU00152

Clutch lever

The clutch lever is located at the left handlebar grip. To disengage the clutch, pull the lever toward the handlebar grip. To engage the clutch, release the lever. The lever should be pulled rapidly and released slowly for smooth clutch operation.

The clutch lever is equipped with a clutch switch, which is part of the ignition circuit cut-off system. (See page 3-19 for an explanation of the ignition circuit cut-off system.)




1. Shift pedal

EAU00157

Shift pedal

The shift pedal is located on the left side of the engine and is used in combination with the clutch lever when shifting the gears of the 6-speed constant-mesh transmission equipped on this motorcycle.




1. Arrow mark
2. Brake lever position adjusting dial
3. Brake lever
- a. Distance between brake lever and handlebar grip

EAU00161

Brake lever

The brake lever is located at the right handlebar grip. To apply the front brake, pull the lever toward the handlebar grip. The brake lever is equipped with a position adjusting dial. To adjust the distance between the brake lever and the handlebar grip, turn the adjusting dial while holding the lever pushed away from the handlebar grip. Make sure that the appropriate setting on the adjusting dial is aligned with the arrow mark on the brake lever.

INSTRUMENT AND CONTROL FUNCTIONS




1. Brake pedal

EAU00162

Brake pedal

The brake pedal is on the right side of the motorcycle. To apply the rear brake, press down on the brake pedal.



1. Fuel tank cap lock cover
2. Unlock.

EAU02935

Fuel tank cap

To open the fuel tank cap

Open the fuel tank cap lock cover, insert the key into the lock, and then turn it 1/4 turn clockwise. The lock will be released and the fuel tank cap can be opened.

To close the fuel tank cap

1. Push the fuel tank cap into position with the key inserted in the lock.

2. Turn the key counterclockwise to the original position, remove it, and then close the lock cover.

NOTE: _____

The fuel tank cap cannot be closed unless the key is in the lock. In addition, the key cannot be removed if the cap is not properly closed and locked.

EWA00025




WARNING _____

Make sure that the fuel tank cap is properly closed before riding.

INSTRUMENT AND CONTROL FUNCTIONS

3



1. Fuel tank filler tube
2. Fuel level

EAU003753

Fuel

Make sure that there is sufficient fuel in the tank. Fill the fuel tank to the bottom of the filler tube as shown.

EW000130

! WARNING

- Do not overfill the fuel tank, otherwise it may overflow when the fuel warms up and expands.
- Avoid spilling fuel on the hot engine.

EAU00186

CAUTION:

- Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts.
- For Germany only: Whenever replacement is necessary, use a fuel tank cap of the same special design as the original.

EAU04255

Recommended fuel:
REGULAR UNLEADED
GASOLINE ONLY

Fuel tank capacity:

Total amount:

19 L

Reserve amount:

3.1 L

ECA00104

CAUTION:

Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts, such as the valves and piston rings, as well as to the exhaust system.


Your Yamaha engine has been designed to use regular unleaded gasoline with a research octane number of 91 or higher. If knocking (or pinging) occurs, use a gasoline of a different brand or premium unleaded fuel. Use of unleaded fuel will extend spark plug life and reduce maintenance costs.

EAU00196

Fuel tank breather hose (for Germany only)

Before operating the motorcycle:


- Check the fuel tank breather hose connection.
- Check the fuel tank breather hose for cracks or damage, and replace it if damaged.
- Make sure that the end of the fuel tank breather hose is not blocked and clean it if necessary.



1. Fuel tank breather hose

INSTRUMENT AND CONTROL FUNCTIONS

3



1. Starter (choke) lever “|↘|”

EAU02973

Starter (choke) lever “|↘|”

Starting a cold engine requires a richer air-fuel mixture, which is supplied by the starter (choke).


Move the lever in direction ① to turn on the starter (choke).

Move the lever in direction ② to turn off the starter (choke).

ECA00038

CAUTION:

Do not use the starter (choke) for more than 3 minutes as the exhaust pipe may discolor from excessive heat. In addition, extended use of the starter (choke) will cause after-burning. If this occurs, turn off the starter (choke).



1. Unlock.


EAU04158

Seat

To remove the seat

1. Insert the key into the helmet holder lock, and then turn it as shown.
2. Pull the seat off.

INSTRUMENT AND CONTROL FUNCTIONS




1. Seat holder
2. Projection (× 2)

To install the seat

1. Insert the projections on the front of the seat into the seat holder as shown.
2. Push the rear of the seat down to lock it in place.
3. Remove the key.

NOTE: _____
Make sure that the seat is properly secured before riding.



1. Helmet holder
2. Unlock.

Helmet holder

To open the helmet holder, insert the key into the lock, and then turn the key as shown.


To lock the helmet holder, turn the key to the original position, and then remove it.

EAU00261

EW000030



WARNING _____
Never ride with a helmet attached to the helmet holder, since the helmet may hit objects, causing loss of control and possibly an accident.



1. U-LOCK bar
2. Strap (× 3)
3. Lock of the U-LOCK

Storage compartment

EAU04275

This storage compartment is designed to hold an optional genuine Yamaha U-LOCK. (Other locks may not fit.) When placing a U-LOCK in the storage compartment, securely fasten it with the straps. When the U-LOCK is not in the storage compartment, be sure to secure the straps to prevent losing them. When storing the owner's manual or other documents in the storage compartment, be sure to wrap them in a plastic bag so that they will not get wet. When washing the motorcycle, be careful not to let any water enter the storage compartment.

INSTRUMENT AND CONTROL FUNCTIONS

Adjusting the front fork


This front fork is equipped with spring preload adjusting bolts, rebound damping force adjusting screws and compression damping force adjusting screws.

EAU01862

EW000035

⚠ WARNING


Always adjust both fork legs equally, otherwise poor handling and loss of stability may result.



1. Spring preload adjusting bolt

Spring preload

To increase the spring preload and thereby harden the suspension, turn the adjusting bolt on each fork leg in direction (a). To decrease the spring preload and thereby soften the suspension, turn the adjusting bolt on each fork leg in direction (b).




1. Current setting
2. Front fork cap bolt

NOTE: Align the appropriate groove on the adjusting mechanism with the top of the front fork cap bolt.

	Setting
Minimum (soft)	8
Standard	5
Maximum (hard)	1

INSTRUMENT AND CONTROL FUNCTIONS

EC000015




1. Rebound damping force adjusting screw

Rebound damping force

To increase the rebound damping force and thereby harden the rebound damping, turn the adjusting screw on each fork leg in direction (a). To decrease the rebound damping force and thereby soften the rebound damping, turn the adjusting screw on each fork leg in direction (b).

Minimum (soft)	10 clicks in direction (b)*
Standard	7 clicks in direction (b)*
Maximum (hard)	1 click in direction (b)*

* With the adjusting screw fully turned in direction (a)



1. Compression damping force adjusting screw

Compression damping force

To increase the compression damping force and thereby harden the compression damping, turn the adjusting screw on each fork leg in direction (a). To decrease the compression damping force and thereby soften the compression damping, turn the adjusting screw on each fork leg in direction (b).

Minimum (soft)	10 clicks in direction (b)*
Standard	7 clicks in direction (b)*
Maximum (hard)	1 click in direction (b)*

* With the adjusting screw fully turned in direction (a)

CAUTION:

Never attempt to turn an adjusting mechanism beyond the maximum or minimum settings.

NOTE:

Although the total number of clicks of a damping force adjusting mechanism may not exactly match the above specifications due to small differences in production, the actual number of clicks always represents the entire adjusting range. To obtain a precise adjustment, it would be advisable to check the number of clicks of each damping force adjusting mechanism and to modify the specifications as necessary.


INSTRUMENT AND CONTROL FUNCTIONS

Adjusting the shock absorber assembly

EAU03643

This shock absorber assembly is equipped with a spring preload adjusting ring, a rebound damping force adjusting knob and a compression damping force adjusting screw.

ECA00071




1. Spring preload adjusting ring
2. Position indicator

Spring preload

To increase the spring preload and thereby harden the suspension, turn the adjusting ring in direction Ⓐ. To decrease the spring preload and thereby soften the suspension, turn the adjusting ring in direction Ⓑ.

	Setting
Minimum (soft)	1
Standard	3
Maximum (hard)	7



1. Rebound damping force adjusting knob

Rebound damping force

To increase the rebound damping force and thereby harden the rebound damping, turn the adjusting knob in direction Ⓐ. To decrease the rebound damping force and thereby soften the rebound damping, turn the adjusting knob in direction Ⓑ.

Minimum (soft)	25 clicks in direction Ⓑ*
Standard	10 clicks in direction Ⓑ*
Maximum (hard)	3 clicks in direction Ⓑ*


* With the adjusting knob fully turned in direction Ⓐ

INSTRUMENT AND CONTROL FUNCTIONS

EAU00315

NOTE:

Although the total number of clicks of the rebound damping force adjusting mechanism may not exactly match the above specifications due to small differences in production, the actual number of clicks always represents the entire adjusting range. To obtain a precise adjustment, it would be advisable to check the number of clicks of the rebound damping force adjusting mechanism and to modify the specifications as necessary.



1. Compression damping force adjusting screw
2. Position indicator

Compression damping force

To harden the compression damping, decrease the setting by turning the adjusting screw. To soften the compression damping, increase the setting by turning the adjusting screw. Make sure that the position indicator is aligned with the appropriate setting.

	Setting
Minimum (soft)	6
Standard	4
Maximum (hard)	1

⚠ WARNING

This shock absorber contains highly pressurized nitrogen gas. For proper handling, read and understand the following information before handling the shock absorber. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling.

- Do not tamper with or attempt to open the gas cylinder.
- Do not subject the shock absorber to an open flame or other high heat sources, otherwise it may explode due to excessive gas pressure.
- Do not deform or damage the gas cylinder in any way, as this will result in poor damping performance.
- Always have a Yamaha dealer service the shock absorber.

INSTRUMENT AND CONTROL FUNCTIONS

EAU01580

Matching the front and rear suspension settings

Use this table as a guide to match the suspension and damping adjustments of the front fork and shock absorber assembly according to various load conditions.

Load condition	Front fork adjustment			Shock absorber assembly adjustment		
	Spring preload	Compression damping force	Rebound damping force	Spring preload	Compression damping force	Rebound damping force
Rider only	1–8	1–10	1–10	1–5	1–6	3–25
With passenger	1–8	1–10	1–10	3–7	1–4	3–10


EC000015

CAUTION:

Never attempt to turn an adjusting mechanism beyond the maximum or minimum settings.

EAU00330

EW000044



1. Luggage strap holder (× 4)

EAU04276

Luggage strap holders

There are four luggage strap holders, two of which can be turned out for easier access.

Sidestand

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the motorcycle upright.

NOTE:

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See further down for an explanation of the ignition circuit cut-off system.)

! WARNING

The motorcycle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check this system regularly as described below and have a Yamaha dealer repair it if it does not function properly.

INSTRUMENT AND CONTROL FUNCTIONS

EAU03720

Ignition circuit cut-off system

The ignition circuit cut-off system (comprising the sidestand switch, clutch switch and neutral switch) has the following functions.

- It prevents starting when the transmission is in gear and the sidestand is up, but the clutch lever is not pulled.
- It prevents starting when the transmission is in gear and the clutch lever is pulled, but the sidestand is still down.
- It cuts the running engine when the transmission is in gear and the sidestand is moved down.

Periodically check the operation of the ignition circuit cut-off system according to the following procedure.

EW000045

WARNING

If a malfunction is noted, have a Yamaha dealer check the system before riding.

INSTRUMENT AND CONTROL FUNCTIONS

With the engine turned off:
1. Move the sidestand down.
2. Make sure that the engine stop switch is set to “○”.
3. Turn the key to “ON”.
4. Shift the transmission into the neutral position.
5. Push the start switch.
Does the engine start?

YES NO

NOTE: _____
This check is most reliable if performed with
a warmed-up engine.

The neutral switch may be defective.
The motorcycle should not be ridden until
checked by a Yamaha dealer.

With the engine still running:
6. Move the sidestand up.
7. Keep the clutch lever pulled.
8. Shift the transmission into gear.
9. Move the sidestand down.
Does the engine stall?

YES NO

The sidestand switch may be defective.
The motorcycle should not be ridden until
checked by a Yamaha dealer.

After the engine has stalled:
10. Move the sidestand up.
11. Keep the clutch lever pulled.
12. Push the start switch.
Does the engine start?

YES NO

The clutch switch may be defective.
The motorcycle should not be ridden until
checked by a Yamaha dealer.

The system is OK. **The motorcycle can be ridden.**

Pre-operation check list 4-1

PRE-OPERATION CHECKS

The condition of a vehicle is the owner's responsibility. Vital components can start to deteriorate quickly and unexpectedly, even if the vehicle remains unused (for example, as a result of exposure to the elements). Any damage, fluid leakage or loss of tire air pressure could have serious consequences. Therefore, it is very important, in addition to a thorough visual inspection, to check the following points before each ride.

Pre-operation check list

ITEM	CHECKS	PAGE
Fuel	<ul style="list-style-type: none">• Check fuel level in fuel tank.• Refuel if necessary.• Check fuel line for leakage.	3-9
Engine oil	<ul style="list-style-type: none">• Check oil level in engine.• If necessary, add recommended oil to specified level.• Check vehicle for oil leakage.	6-10
Coolant	<ul style="list-style-type: none">• Check coolant level in reservoir.• If necessary, add recommended coolant to specified level.• Check cooling system for leakage.	6-13–6-14
Front brake	<ul style="list-style-type: none">• Check operation.• If soft or spongy, have Yamaha dealer bleed hydraulic system.• Check fluid level in reservoir.• If necessary, add recommended brake fluid to specified level.• Check hydraulic system for leakage.	6-27–6-28
Rear brake	<ul style="list-style-type: none">• Check operation.• If soft or spongy, have Yamaha dealer bleed hydraulic system.• Check fluid level in reservoir.• If necessary, add recommended brake fluid to specified level.• Check hydraulic system for leakage.	6-25–6-28
Clutch	<ul style="list-style-type: none">• Check operation.• Lubricate cable if necessary.• Check lever free play.• Adjust if necessary.	6-25

PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
Throttle grip	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Check free play. • If necessary, have Yamaha dealer make adjustment or lubricate. 	6-20
Control cables	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate if necessary. 	6-31
Drive chain	<ul style="list-style-type: none"> • Check chain slack. • Adjust if necessary. • Check chain condition. • Lubricate if necessary. 	6-29, 6-30
Wheels and tires	<ul style="list-style-type: none"> • Check for damage. • Check tire condition and tread depth. • Check air pressure. • Correct if necessary. 	6-21–6-24
Brake and shift pedals	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate pedal pivoting points if necessary. 	6-31
Brake and clutch levers	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate lever pivoting points if necessary. 	6-32
Sidestand	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate pivot if necessary. 	6-32
Chassis fasteners	<ul style="list-style-type: none"> • Make sure that all nuts, bolts and screws are properly tightened. • Tighten if necessary. 	—
Instruments, lights, signals and switches	<ul style="list-style-type: none"> • Check operation. • Correct if necessary. 	—
Sidestand switch	<ul style="list-style-type: none"> • Check operation of ignition circuit cut-off system. • If system is defective, have Yamaha dealer check vehicle. 	3-18
Air intake duct	<ul style="list-style-type: none"> • Check that the screen is not clogged. • Clean if necessary. 	6-19

PRE-OPERATION CHECKS

NOTE:

Pre-operation checks should be made each time the motorcycle is used. Such an inspection can be accomplished in a very short time; and the added safety it assures is more than worth the time involved.

EWA00033

 WARNING

If any item in the Pre-operation check list is not working properly, have it inspected and repaired before operating the motorcycle.

OPERATION AND IMPORTANT RIDING POINTS

Starting the engine	5-1
Starting a warm engine	5-3
Shifting	5-3
Recommended shift points (for Switzerland only)	5-4
Tips for reducing fuel consumption	5-4
Engine break-in	5-5
Parking	5-6

EAU00373

EAU03818*

EC000035

⚠ WARNING

- Become thoroughly familiar with all operating controls and their functions before riding. Consult a Yamaha dealer regarding any control or function that you do not thoroughly understand.
- Never start the engine or operate it in a closed area for any length of time. Exhaust fumes are poisonous, and inhaling them can cause loss of consciousness and death within a short time. Always make sure that there is adequate ventilation.
- Before starting out, make sure that the sidestand is up. If the sidestand is not raised completely, it could contact the ground and distract the operator, resulting in a possible loss of control.

Starting the engine

In order for the ignition circuit cut-off system to enable starting, one of the following conditions must be met:

- The transmission is in the neutral position.
- The transmission is in gear with the clutch lever pulled and the sidestand up.

EW000054

⚠ WARNING

- Before starting the engine, check the function of the ignition circuit cut-off system according to the procedure described on page 3-20.
 - Never ride with the sidestand down.
1. Turn the key to "ON" and make sure that the engine stop switch is set to "○".

CAUTION:

If the fuel level warning light comes on, check the fuel level, and, if necessary, refuel as soon as possible.

2. Shift the transmission into the neutral position.

NOTE:

When the transmission is in the neutral position, the neutral indicator light should be on, otherwise have a Yamaha dealer check the electrical circuit.

3. Turn the starter (choke) on and completely close the throttle. (See page 3-11 for starter (choke) operation.)
4. Start the engine by pushing the start switch.

OPERATION AND IMPORTANT RIDING POINTS

NOTE:

If the engine fails to start, release the start switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 10 seconds on any one attempt.

EC000038

CAUTION:

- The oil level warning light and fuel level warning light should come on when the start switch is pushed, and they should go off when the start switch is released.
- If the oil level warning light flickers or remains on after starting, immediately stop the engine, and then check the engine oil level and the vehicle for oil leakage. If necessary, add engine oil, and then check the warning light again. If the warning light does not come on when pushing the start switch, or if it does

not go off after starting with sufficient engine oil, have a Yamaha dealer check the electrical circuit.

- If the fuel level warning light remains on after starting, stop the engine, and then check the fuel level. If necessary, refuel as soon as possible, and then check the warning light again. If the warning light does not come on when pushing the start switch, or if it does not go off after starting with sufficient fuel, have a Yamaha dealer check the electrical circuit.

5. After starting the engine, move the starter (choke) lever back halfway.

ECA00045

CAUTION:

For maximum engine life, never accelerate hard when the engine is cold!

6. When the engine is warm, turn the starter (choke) off.

NOTE:


The engine is warm when it responds normally to the throttle with the starter (choke) turned off.

OPERATION AND IMPORTANT RIDING POINTS

Starting a warm engine

Follow the same procedure as for starting a cold engine with the exception that the starter (choke) is not required when the engine is warm.

EAU01258



1. Shift pedal
N. Neutral position

EAU00423

Shifting

Shifting gears lets you control the amount of engine power available for starting off, accelerating, climbing hills, etc.

The gear positions are shown in the illustration.

NOTE:

To shift the transmission into the neutral position, press the shift pedal down repeatedly until it reaches the end of its travel, and then slightly raise it.

EC000048

CAUTION:

- Even with the transmission in the neutral position, do not coast for long periods of time with the engine off, and do not tow the motorcycle for long distances. The transmission is properly lubricated only when the engine is running. Inadequate lubrication may damage the transmission.
- Always use the clutch while changing gears to avoid damaging the engine, transmission, and drive train, which are not designed to withstand the shock of forced shifting.

EAU02937

Recommended shift points (for Switzerland only)

The recommended shift points during acceleration are shown in the table below.

	Shift point (km/h)
1st → 2nd	20
2nd → 3rd	30
3rd → 4th	40
4th → 5th	50
5th → 6th	60

NOTE:

When shifting down two gears at a time, reduce the speed accordingly (e.g., down to 35 km/h when shifting from 5th to 3rd gear).

EAU00424

Tips for reducing fuel consumption

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Thoroughly warm up the engine.
- Turn the starter (choke) off as soon as possible.
- Shift up swiftly, and avoid high engine speeds during acceleration.
- Do not rev the engine while shifting down, and avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).

OPERATION AND IMPORTANT RIDING POINTS

Engine break-in

EAU01128

There is never a more important period in the life of your engine than the period between 0 and 1,600 km. For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1,600 km. The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

0–1,000 km

Avoid prolonged operation above 6,500 r/min.

1,000–1,600 km

Avoid prolonged operation above 8,000 r/min.

EAU03749*

EC000052*

CAUTION:

After 1,000 km of operation, the engine oil must be changed and the oil filter cartridge replaced.

1,600 km and beyond

The vehicle can now be operated normally.

EC000053

CAUTION:

- Keep the engine speed out of the tachometer red zone.
 - If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.
-

EAU00460

Parking

When parking, stop the engine, and then remove the key from the main switch.

EW000058

WARNING

- **Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them.**
 - **Do not park on a slope or on soft ground, otherwise the motorcycle may overturn.**
-

PERIODIC MAINTENANCE AND MINOR REPAIR

Owner's tool kit	6-1	Checking and lubricating the cables	6-31
Periodic maintenance and lubrication chart	6-2	Checking and lubricating the throttle grip and cable	6-31
Removing and installing cowlings	6-5	Checking and lubricating the brake and shift pedals	6-31
Checking the spark plugs	6-8	Checking and lubricating the brake and clutch levers	6-32
Engine oil and oil filter cartridge	6-10	Checking and lubricating the sidestand	6-32
Coolant	6-13	Lubricating the rear suspension	6-32
Cleaning the air filter element	6-17	Checking the front fork	6-33
Checking the air vent hose	6-18	Checking the steering	6-33
Air intake duct	6-19	Checking the wheel bearings	6-34
Adjusting the carburetors	6-19	Battery	6-35
Adjusting the engine idling speed	6-19	Replacing the fuses	6-36
Adjusting the throttle cable free play	6-20	Replacing the headlight bulb	6-37
Adjusting the valve clearance	6-20	Replacing the tail/brake light bulb	6-38
Tires	6-21	Replacing a turn signal light bulb	6-39
Cast wheels	6-24	Supporting the motorcycle	6-39
Adjusting the clutch lever free play	6-25	Front wheel	6-40
Adjusting the brake pedal position	6-25	Rear wheel	6-41
Adjusting the rear brake light switch	6-26	Troubleshooting	6-43
Checking the front and rear brake pads	6-27	Troubleshooting charts	6-44
Checking the brake fluid level	6-27		
Changing the brake fluid	6-28		
Drive chain slack	6-29		
Lubricating the drive chain	6-30		

EAU00464


Safety is an obligation of the owner. Periodic inspection, adjustment and lubrication will keep your vehicle in the safest and most efficient condition possible. The most important points of inspection, adjustment, and lubrication are explained on the following pages.

The intervals given in the periodic maintenance and lubrication chart should be simply considered as a general guide under normal riding conditions. However, **DEPENDING ON THE WEATHER, TERRAIN, GEOGRAPHICAL LOCATION, AND INDIVIDUAL USE, THE MAINTENANCE INTERVALS MAY NEED TO BE SHORTENED.**

EW000060

⚠ WARNING

If you are not familiar with motorcycle maintenance work, have a Yamaha dealer do it for you.



1. Owner's tool kit

EAU01299

Owner's tool kit

The owner's tool kit is located inside the storage compartment under the seat. (See page 3-11 for seat removal procedures.)

The service information included in this manual and the tools provided in the owner's tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, additional tools such as a torque wrench may be necessary to perform certain maintenance work correctly.

NOTE:

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

EW000063

⚠ WARNING

Modifications not approved by Yamaha may cause loss of performance and render the vehicle unsafe for use. Consult a Yamaha dealer before attempting any changes.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03685

Periodic maintenance and lubrication chart

NOTE:

- The annual checks must be performed every year, except if a kilometer-based maintenance is performed instead.
- From 50,000 km, repeat the maintenance intervals starting from 10,000 km.
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (× 1,000 km)					ANNUAL CHECK
			1	10	20	30	40	
1	* Fuel line	• Check fuel hoses for cracks or damage.		√	√	√	√	√
2	* Fuel filter	• Check condition.			√		√	
3	Spark plugs	• Check condition. • Clean and regap.		√		√		
		• Replace.			√		√	
4	* Valves	• Check valve clearance. • Adjust.	Every 40,000 km					
5	Air filter element	• Clean.		√		√		
		• Replace.			√		√	
6	Clutch	• Check operation. • Adjust.	√	√	√	√	√	
7	* Front brake	• Check operation, fluid level and vehicle for fluid leakage. (See NOTE on page 6-4.)	√	√	√	√	√	√
		• Replace brake pads.	Whenever worn to the limit					
8	* Rear brake	• Check operation, fluid level and vehicle for fluid leakage. (See NOTE on page 6-4.)	√	√	√	√	√	√
		• Replace brake pads.	Whenever worn to the limit					

PERIODIC MAINTENANCE AND MINOR REPAIR

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (× 1,000 km)					ANNUAL CHECK
			1	10	20	30	40	
9	* Brake hoses	• Check for cracks or damage.		√	√	√	√	√
		• Replace. (See NOTE on page 6-4.)	Every 4 years					
10	* Wheels	• Check runout and for damage.		√	√	√	√	
11	* Tires	• Check tread depth and for damage. • Replace if necessary. • Check air pressure. • Correct if necessary.		√	√	√	√	√
12	* Wheel bearings	• Check bearing for looseness or damage.		√	√	√	√	
13	* Swingarm	• Check operation and for excessive play.		√	√	√	√	
		• Lubricate with lithium-soap-based grease.	Every 50,000 km					
14	Drive chain	• Check chain slack. • Make sure that the rear wheel is properly aligned. • Clean and lubricate.	Every 1,000 km and after washing the motorcycle or riding in the rain					
15	* Steering bearings	• Check bearing play and steering for roughness.	√	√	√	√	√	
		• Lubricate with lithium-soap-based grease.	Every 50,000 km					
16	* Chassis fasteners	• Make sure that all nuts, bolts and screws are properly tightened.		√	√	√	√	√
17	Sidestand	• Check operation. • Lubricate.		√	√	√	√	√
18	* Sidestand switch	• Check operation.	√	√	√	√	√	√
19	* Front fork	• Check operation and for oil leakage.		√	√	√	√	
20	* Shock absorber assembly	• Check operation and shock absorber for oil leakage.		√	√	√	√	
21	* Rear suspension relay arm and connecting arm pivoting points	• Check operation.		√	√	√	√	
		• Lubricate with lithium-soap-based grease.			√		√	
22	* Carburetors	• Check starter (choke) operation. • Adjust engine idling speed and synchronization.	√	√	√	√	√	√

PERIODIC MAINTENANCE AND MINOR REPAIR


NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (× 1,000 km)					ANNUAL CHECK
			1	10	20	30	40	
23	Engine oil	<ul style="list-style-type: none"> • Change. • Check oil level and vehicle for oil leakage. 	√	√	√	√	√	√
24	Engine oil filter cartridge	<ul style="list-style-type: none"> • Replace. 	√		√		√	
25	* Cooling system	<ul style="list-style-type: none"> • Check coolant level and vehicle for coolant leakage. • Change. 		√	√	√	√	√
			Every 3 years					
26	* Front and rear brake switches	<ul style="list-style-type: none"> • Check operation. 	√	√	√	√	√	√
27	Moving parts and cables	<ul style="list-style-type: none"> • Lubricate. 		√	√	√	√	√
28	* Lights, signals and switches	<ul style="list-style-type: none"> • Check operation. • Adjust headlight beam. 	√	√	√	√	√	√

EAU03884

NOTE:

- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level.
 - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Cowling A
2. Cowling B

EAU01065


Removing and installing cowlings

The cowlings shown above need to be removed to perform some of the maintenance jobs described in this chapter.



1. Cowling C
2. Cowling D

Refer to this section each time a cowling needs to be removed and installed.



1. Bolt (× 3 on each side)


EAU04277

Cowlings A and C

To remove one of the cowlings


1. Remove the bolts.

PERIODIC MAINTENANCE AND MINOR REPAIR




Bolt (× 6)

Bolt (× 7)



1. Bolt (× 5 on each side)




1. Auxiliary light coupler
2. Turn signal connector (× 2)

2. Disconnect the turn signal connectors (and, for the left-side cowling, also the auxiliary light coupler), and then take the cowling off.

To install the cowling

1. Connect the turn signal connectors (and, for the left-side cowling, also the auxiliary light coupler).
2. Place the cowling in the original position, and then install the bolts.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Screw (× 2)

EAU03595

Cowling B


To remove the cowling

1. Remove the seat. (See page 3-11 for seat removal and installation procedures.)
2. Remove the screws, and then pull the cowling off as shown.

NOTE: _____
Pull the cowling up, then back to remove it.

To install the cowling

1. Place the cowling in the original position, and then install the screws.
2. Install the seat.



1. Bolt (× 2)
2. Screw

EAU04278

Cowling D


To remove the cowling

1. Remove the seat and cowling B. (See pages 3-11 and 6-7 for seat and cowling removal and installation procedures.)
2. Remove the grab bar by removing the bolts.
3. Remove the screw, and then pull the cowling off as shown.


To install the cowling

1. Place the cowling in the original position, and then install the screw.
2. Install the grab bar by installing the bolts.
3. Install the cowling and the seat.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Spark plug cap (× 2 on each side)



1. Spark plug wrench



Checking the spark plugs

EAU03329

The spark plugs are important engine components, which are easy to check. Since heat and deposits will cause any spark plug to slowly erode, the spark plugs should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plugs can reveal the condition of the engine.

To remove a spark plug

1. Remove the spark plug cap.

2. Remove the spark plug as shown, with the spark plug wrench included in the owner's tool kit.

To check the spark plugs

1. Check that the porcelain insulator around the center electrode on each spark plug is a medium-to-light tan (the ideal color when the motorcycle is ridden normally).
2. Check that all spark plugs installed in the engine have the same color.


NOTE:

_____ If any spark plug shows a distinctly different color, the engine could be defective. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the motorcycle.

PERIODIC MAINTENANCE AND MINOR REPAIR

3. Check each spark plug for electrode erosion and excessive carbon or other deposits, and replace it if necessary.

Specified spark plug:
CR9E (NGK) or
U27ESR-N (DENSO)



a. Spark plug gap

To install a spark plug

1. Measure the spark plug gap with a wire thickness gauge and, if necessary, adjust the gap to specification.

Spark plug gap:
0.7–0.8 mm

2. Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.
3. Install the spark plug with the spark plug wrench, and then tighten it to the specified torque.

Tightening torque:
Spark plug:
12.5 Nm (1.25 m.kgf)

NOTE: _____
If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

4. Install the spark plug cap.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU04279


Engine oil and oil filter cartridge

The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil filter cartridge replaced at the intervals specified in the periodic maintenance and lubrication chart.

To check the engine oil level

1. Place the motorcycle on a level surface and hold it in an upright position.


NOTE: _____
Make sure that the motorcycle is positioned straight up when checking the oil level. A slight tilt to the side can result in a false reading.



1. Engine oil level check window
 2. Maximum level mark
 3. Minimum level mark
2. Start the engine, warm it up for several minutes, and then turn it off.
 3. Wait a few minutes until the oil settles, and then check the oil level through the check window located at the bottom-right side of the crankcase.

NOTE: _____
The engine oil should be between the minimum and maximum level marks.

4. If the engine oil is below the minimum level mark, add sufficient oil of the recommended type to raise it to the correct level.




1. Engine oil filler cap

To change the engine oil (with or without oil filter cartridge replacement)


1. Remove cowling A. (See page 6-5 for cowling removal and installation procedures.)
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Place an oil pan under the engine to collect the used oil.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Engine oil drain bolt


4. Remove the engine oil filler cap and drain bolt to drain the oil from the crankcase.



1. Oil filter cartridge

2. Oil filter wrench

5. Remove the oil filter cartridge with an oil filter wrench.



1. O-ring

6. Apply a thin coat of engine oil to the O-ring of the new oil filter cartridge.

6

NOTE: _____
Skip steps 5–7 if the oil filter cartridge is not being replaced.

NOTE: _____
An oil filter wrench is available at a Yamaha dealer.

NOTE: _____
Make sure that the O-ring is properly seated.

7. Install the new oil filter cartridge, and then tighten it to the specified torque with a torque wrench.

Tightening torque:
Oil filter cartridge:
17 Nm (1.7 m-kgf)

PERIODIC MAINTENANCE AND MINOR REPAIR

8. Install the engine oil drain bolt, and then tighten it to the specified torque.

Tightening torque:
Engine oil drain bolt:
43 Nm (4.3 m·kgf)

9. Add the specified amount of the recommended engine oil, and then install and tighten the oil filler cap.

Recommended engine oil:

See page 8-1.

Oil quantity:

Without oil filter cartridge
replacement:

2.6 L

With oil filter cartridge
replacement:

2.9 L

Total amount (dry engine):

3.5 L

ECA00105

CAUTION:

- In order to prevent clutch slippage (since the engine oil also lubricates the clutch), do not mix any chemical additives with the oil or use oils of grade “CD” or higher. In addition, do not use oils labeled “ENERGY CONSERVING II” or higher.
- Make sure that no foreign material enters the crankcase.

10. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.

NOTE:

After the engine is started, the engine oil level warning light should go off if the oil level is sufficient.

EC000067

CAUTION:

If the oil level warning light flickers or remains on, immediately turn the engine off and have a Yamaha dealer check the vehicle.

11. Turn the engine off, and then check the oil level and correct it if necessary.
12. Install the cowling.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03987

Coolant


The coolant level should be checked before each ride. In addition, the coolant must be changed at the intervals specified in the periodic maintenance and lubrication chart.

To check the coolant level

1. Place the motorcycle on a level surface and hold it in an upright position.

NOTE:

- The coolant level must be checked on a cold engine since the level varies with engine temperature.
- Make sure that the motorcycle is positioned straight up when checking the coolant level. A slight tilt to the side can result in a false reading.



1. Maximum level mark
2. Minimum level mark

2. Check the coolant level in the coolant reservoir.

NOTE:

The coolant should be between the minimum and maximum level marks.

3. If the coolant is at or below the minimum level mark, remove the seat (See page 3-11 for seat removal and installation procedures.), and then open the coolant reservoir cap.
4. Add coolant or distilled water to raise the coolant to the specified level, close the coolant reservoir cap, and then install the seat.

Coolant reservoir capacity:
0.55 L

EC000080

CAUTION:

- If coolant is not available, use distilled water or soft tap water instead. Do not use hard water or salt water since it is harmful to the engine.
- If water has been used instead of coolant, replace it with coolant as soon as possible, otherwise the engine may not be sufficiently cooled and the cooling system will not be protected against frost and corrosion.
- If water has been added to the coolant, have a Yamaha dealer check the antifreeze content of the coolant as soon as possible, otherwise the effectiveness of the coolant will be reduced.

PERIODIC MAINTENANCE AND MINOR REPAIR


EW000067

⚠ WARNING

Never attempt to remove the radiator cap when the engine is hot.

NOTE:

- The radiator fan is automatically switched on or off according to the coolant temperature in the radiator.
- If the engine overheats, see page 6-45 for further instructions.




1. Bolt (× 2)
2. Coolant reservoir

EAU04280

To change the coolant

1. Place the motorcycle on a level surface and let the engine cool if necessary.
2. Remove the seat. (See page 3-11 for seat removal and installation procedures.)
3. Remove cowl D. (See page 6-7 for cowl removal and installation procedures.)
4. Remove the coolant reservoir by removing the bolts.
5. Drain the coolant from the coolant reservoir.
6. Remove cowlings A and C. (See page 6-5 for cowl removal and installation procedures.)



1. Fuel tank bolt (× 2)


7. Remove the fuel tank bolts, and then lift the fuel tank. (Do not remove the fuel hoses.)

EW000071

⚠ WARNING

- Make sure that the fuel tank is well supported.
- Do not tilt or pull the fuel tank too much, otherwise the fuel hoses may come loose, which could cause fuel leakage.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Clamp screw (× 2)
2. Right air intake duct

8. Remove the right air intake duct by loosening the clamp screws.



1. Radiator cap

9. Remove the radiator cap.


EW000067



WARNING

Never attempt to remove the radiator cap when the engine is hot.

10. Place a container under the engine to collect the used coolant.



1. Water pump drain bolt
2. Cylinder drain bolt (× 2)

11. Remove the water pump drain bolt to drain the cooling system.
12. Remove the cylinder drain bolts to drain the cooling system.
13. After the coolant is completely drained, thoroughly flush the cooling system with clean tap water.
14. Install the water pump drain bolt and cylinder drain bolts, and then tighten them to the specified torques.

PERIODIC MAINTENANCE AND MINOR REPAIR

ECA00041

Tightening torques:

Water pump drain bolt:

10 Nm (1.0 m·kgf)

Cylinder drain bolt:

7.0 Nm (0.7 m·kgf)

15. Install the coolant reservoir by installing the bolts.
16. Pour the specified amount of recommended coolant into the radiator and reservoir.

Antifreeze/water mixture ratio:

1:1

Recommended anti-freeze:

High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines

Coolant quantity:

Total amount:

1.95 L

Coolant reservoir capacity:


0.55 L

CAUTION:


Hard water or salt water is harmful to the engine. You may use soft water if you can't get distilled water.

17. Install the radiator cap and the coolant reservoir cap, start the engine, let it idle for several minutes, and then turn it off.
18. Remove the radiator cap to check the coolant level in the radiator. If necessary, add sufficient coolant until it reaches the top of the radiator, and then install the radiator cap.
19. Check the coolant level in the reservoir. If necessary, remove the coolant reservoir cap, add coolant to the maximum level mark, and then install the cap.
20. Start the engine, and then check the vehicle for coolant leakage. If coolant is leaking, have a Yamaha dealer check the cooling system.
21. Install the right air intake duct, and then tighten the clamp screws.
22. Place the fuel tank in the original position, and then install the bolts.
23. Install the cowlings.
24. Install the seat.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Fuel tank bolt (× 2)



1. Air filter case cover
2. Screw (× 8)



1. Air filter element

Cleaning the air filter element

EAU04281*

The air filter element should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Clean the air filter element more frequently if you are riding in unusually wet or dusty areas.

1. Remove the seat. (See page 3-11 for seat removal and installation procedures.)
2. Remove the fuel tank bolts.
3. Lift the fuel tank to position it away from the air filter case. (Do not disconnect the fuel hoses!)


EW000071

⚠ WARNING

- **Make sure that the fuel tank is well supported.**
 - **Do not tilt or pull the fuel tank too much, otherwise the fuel hoses may come loose, which could cause fuel leakage.**
4. Remove the air filter case cover by removing the screws.

5. Pull the air filter element out.
6. Clean the air filter element with solvent, and then squeeze the remaining solvent out.

PERIODIC MAINTENANCE AND MINOR REPAIR



7. Apply oil of the recommended type to the entire surface of the sponge material, and then squeeze the excess oil out.

NOTE: _____
The air filter element should be wet but not dripping.

Recommended oil:
Engine oil

8. Insert the air filter element into the air filter case.

EC000082*

CAUTION: _____

- Make sure that the air filter element is properly seated in the air filter case.
- The engine should never be operated without the air filter element installed, otherwise the pistons and/or cylinders may become excessively worn.


9. Install the air filter case cover by installing the screws.
10. Place the fuel tank in the original position, and then install the bolts.

EW000072

⚠ WARNING _____

- Before installing the fuel tank, make sure that the fuel hoses are not damaged. If any fuel hose is damaged, do not start the engine but have a Yamaha dealer replace the hose, otherwise fuel may leak.
- Make sure that the fuel hoses are properly connected and routed, and not pinched.

11. Install the seat.



1. Air vent hose

EAU00626

Checking the air vent hose


Periodically check the air vent hose for dust or water that may be deposited in the hose. If dust or water is found, remove the air vent hose, thoroughly clean it, and then install it.

EC000093

CAUTION: _____

Do not operate the motorcycle with the air vent hose removed.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Air intake duct

EAU01335

Air intake duct

Check that the screen of the intake duct is not blocked. Clean the screen if necessary.

6

EAU00630

Adjusting the carburetors

The carburetors are important parts of the engine and require very sophisticated adjustment. Therefore, most carburetor adjustments should be left to a Yamaha dealer, who has the necessary professional knowledge and experience. The adjustment described in the following section, however, may be serviced by the owner as part of routine maintenance.

EC000095

CAUTION:

The carburetors have been set and extensively tested at the Yamaha factory. Changing these settings without sufficient technical knowledge may result in poor performance of or damage to the engine.

EAU00632

Adjusting the engine idling speed

The engine idling speed must be checked and, if necessary, adjusted as follows at the intervals specified in the periodic maintenance and lubrication chart.


1. Start the engine and warm it up for several minutes at 1,000–2,000 r/min while occasionally revving it to 4,000–5,000 r/min.

NOTE:

The engine is warm when it quickly responds to the throttle.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU00637




1. Throttle stop screw

2. Check the engine idling speed and, if necessary, adjust it to specification by turning the throttle stop screw. To increase the engine idling speed, turn the screw in direction **a**. To decrease the engine idling speed, turn the screw in direction **b**.

Engine idling speed:
1,200–1,300 r/min

NOTE:

If the specified idling speed cannot be obtained as described above, have a Yamaha dealer make the adjustment.



a. Throttle cable free play

Adjusting the valve clearance

The valve clearance changes with use, resulting in improper air-fuel mixture and/or engine noise. To prevent this from occurring, the valve clearance must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

EAU00635

Adjusting the throttle cable free play

The throttle cable free play should measure 3–7 mm at the throttle grip. Periodically check the throttle cable free play and, if necessary, have a Yamaha dealer adjust it.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU00658

Tires

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EW000082

WARNING

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.

Tire air pressure (measured on cold tires)		
Load*	Front	Rear
Up to 90 kg	225 kPa (2.25 kgf/cm ² , 2.25 bar)	250 kPa (2.50 kgf/cm ² , 2.50 bar)
90 kg--maximum	250 kPa (2.50 kgf/cm ² , 2.50 bar)	290 kPa (2.90 kgf/cm ² , 2.90 bar)
High-speed riding	250 kPa (2.50 kgf/cm ² , 2.50 bar)	290 kPa (2.90 kgf/cm ² , 2.90 bar)
Maximum load*	180 kg (except for A, CH, S) 178 kg (for A, CH, S)	

* Total weight of rider, passenger, cargo and accessories

EWA00012

WARNING


Because loading has an enormous impact on the handling, braking, performance and safety characteristics of your motorcycle, you should keep the following precautions in mind.

- **NEVER OVERLOAD THE MOTORCYCLE!** Operation of an overloaded motorcycle may result in tire damage, loss of control, or severe injury. Make sure that the total weight of rider, passenger, cargo, and accessories does not exceed the specified maximum load for the vehicle.
- Do not carry along loosely packed items, which can shift during a ride.

PERIODIC MAINTENANCE AND MINOR REPAIR

EW000079

- Securely pack the heaviest items close to the center of the motorcycle and distribute the weight evenly on both sides.
- Adjust the suspension and tire air pressure with regard to the load.
- Check the tire condition and air pressure before each ride.



- 1. Tire sidewall
- a. Tire tread depth

Tire inspection

The tires must be checked before each ride. If the center tread depth reaches the specified limit, if the tire has a nail or glass fragments in it, or if the sidewall is cracked, have a Yamaha dealer replace the tire immediately.

Minimum tire tread depth (front and rear)	1.6 mm
--	--------

NOTE:


The tire tread depth limits may differ from country to country. Always comply with the local regulations.

⚠ WARNING

- Have a Yamaha dealer replace excessively worn tires. Besides being illegal, operating the motorcycle with excessively worn tires decreases riding stability and can lead to loss of control.
- The replacement of all wheel- and brake-related parts, including the tires, should be left to a Yamaha dealer, who has the necessary professional knowledge and experience.

PERIODIC MAINTENANCE AND MINOR REPAIR

EW000080



1. Tire air valve
2. Tire valve core
3. Tire valve cap with seal

Tire information

This motorcycle is equipped with cast wheels and tubeless tires with valves.

⚠ WARNING

- The front and rear tires should be of the same make and design, otherwise the handling characteristics of the motorcycle cannot be guaranteed.
- After extensive tests, only the tires listed below have been approved for this model by Yamaha Motor Co., Ltd.
- Always make sure that the valve caps are securely installed to prevent air pressure leakage.
- Use only the tire valves and valve cores listed below to avoid tire deflation during a high-speed ride.

FRONT

Manufacturer	Size	Model
Dunlop	120/60 ZR17 (55W)	D204F
	120/60 ZR17 M/C (55W)	
Metzeler	120/60 ZR17 (55W)	MEZ1 FRONT
	120/60 ZR17 M/C (55W)	
Bridgestone	120/60 ZR17 (55W)	BT57F
	120/60 ZR17 M/C (55W)	
Michelin	120/60 ZR17 (55W)	MACADAM 90X
	120/60 ZR17 M/C (55W)	

REAR

Manufacturer	Size	Model
Dunlop	160/60 ZR17 (69W)	D204
	160/60 ZR17 M/C (69W)	
Metzeler	160/60 ZR17 (69W)	MEZ1
	160/60 ZR17 M/C (69W)	
Bridgestone	160/60 ZR17 (69W)	BT57
	160/60 ZR17 M/C (69W)	
Michelin	160/60 ZR17 (69W)	MACADAM 90X
	160/60 ZR17 M/C (69W)	

FRONT & REAR

Tire air valve	TR412
Valve core	#9000A (original)

EAU00684

EAU03773

WARNING

This motorcycle is fitted with super-high-speed tires. Note the following points in order to make the most efficient use of these tires.


- Use only the specified replacement tires. Other tires may run the danger of bursting at super high speeds.
- Brand-new tires can have a relatively poor grip on certain road surfaces until they have been “broken in”. Therefore, it is advisable before doing any high-speed riding to ride conservatively for approximately 100 km after installing a new tire.
- The tires must be warmed up before a high-speed run.
- Always adjust the tire air pressure according to the operating conditions.

Cast wheels

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends or warpage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.
- Ride at moderate speeds after changing a tire since the tire surface must first be “broken in” for it to develop its optimal characteristics.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Locknut
2. Clutch lever free play adjusting bolt
- c. Clutch lever free play


EAU00692

Adjusting the clutch lever free play

The clutch lever free play should measure 10–15 mm as shown. Periodically check the clutch lever free play and, if necessary, adjust it as follows.

1. Loosen the locknut at the clutch lever.
2. To increase the clutch lever free play, turn the adjusting bolt in direction Ⓐ. To decrease the clutch lever free play, turn the adjusting bolt in direction Ⓑ.
3. Tighten the locknut.

NOTE: _____
If the specified free play cannot be obtained as described above or if the clutch does not operate correctly, have a Yamaha dealer check the internal clutch mechanism.



- a. Distance between brake pedal and footrest

EAU00712


Adjusting the brake pedal position

The top of the brake pedal should be positioned approximately 42 mm below the top of the footrest as shown. Periodically check the brake pedal position and, if necessary, have a Yamaha dealer adjust it.

EW000109

! WARNING

A soft or spongy feeling in the brake pedal can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the motorcycle. Air in the hydraulic system will diminish the braking performance, which may result in loss of control and an accident.



1. Rear brake light switch
2. Rear brake light switch adjusting nut


EAU00713

Adjusting the rear brake light switch


The rear brake light switch, which is activated by the brake pedal, is properly adjusted when the brake light comes on just before braking takes effect. If necessary, adjust the brake light switch as follows.

Turn the adjusting nut while holding the rear brake light switch in place. To make the brake light come on earlier, turn the adjusting nut in direction ③. To make the brake light come on later, turn the adjusting nut in direction ②.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Brake pad wear indicator (× 2)



1. Brake pad wear indicator (× 2)



1. Minimum level mark

Checking the front and rear brake pads

EAU00715

The front and rear brake pads must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart. Each brake pad is provided with a wear indicator, which allows you to check the brake pad wear without having to disassemble the brake.

To check the brake pad wear, check the position of the wear indicator while applying the brake. If a brake pad has worn to the point that the wear indicator almost touches the brake disc, have a Yamaha dealer replace the brake pads as a set.

Checking the brake fluid level


EAU03294

Insufficient brake fluid may allow air to enter the brake system, possibly causing it to become ineffective.

Before riding, check that the brake fluid is above the minimum level mark and replenish if necessary. A low brake fluid level may indicate worn brake pads and/or brake system leakage. If the brake level is low, be sure to check the brake pads for wear and the brake system for leakage.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03976



1. Minimum level mark

Observe these precautions:

- When checking the fluid level, make sure that the top of the brake fluid reservoir is level.
- Use only the recommended quality brake fluid, otherwise the rubber seals may deteriorate, causing leakage and poor braking performance.

Recommended brake fluid: DOT 4

- Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor braking performance.

- Be careful that water does not enter the brake fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
- Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
- As the brake pads wear, it is normal for the brake fluid level to gradually go down. However, if the brake fluid level goes down suddenly, have a Yamaha dealer check the cause.

Changing the brake fluid

Have a Yamaha dealer change the brake fluid at the intervals specified in the NOTE after the periodic maintenance and lubrication chart. In addition, have the oil seals of the master cylinders and calipers as well as the brake hoses replaced at the intervals listed below or whenever they are damaged or leaking.

- Oil seals: Replace every two years.
- Brake hoses: Replace every four years.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU00744

Drive chain slack


The drive chain slack should be checked before each ride and adjusted if necessary.

To check the drive chain slack

1. Place the motorcycle on a level surface and hold it in an upright position.

NOTE:

When checking and adjusting the drive chain slack, the motorcycle should be positioned straight up and there should be no weight on it.




a. Drive chain slack

2. Shift the transmission into the neutral position.
3. Move the rear wheel by pushing the motorcycle to locate the tightest portion of the drive chain, and then measure the drive chain slack as shown.

Drive chain slack:
20–30 mm

4. If the drive chain slack is incorrect, adjust it as follows.



1. Axle nut
2. Alignment marks
3. Drive chain slack adjusting nut
4. Locknut

EAU03752

To adjust the drive chain slack

1. Loosen the axle nut, then loosen the locknut at each end of the swingarm.
2. To tighten the drive chain, turn the adjusting nut at each end of the swingarm in direction Ⓐ. To loosen the drive chain, turn the adjusting nut at each end of the swingarm in direction Ⓑ, and then push the rear wheel forward.

PERIODIC MAINTENANCE AND MINOR REPAIR

NOTE:

Using the alignment marks on each side of the swingarm, make sure that both adjusting nuts are in the same position for proper wheel alignment.

EC000096

CAUTION:

Improper drive chain slack will overload the engine as well as other vital parts of the motorcycle and can lead to chain slippage or breakage. To prevent this from occurring, keep the drive chain slack within the specified limits.

3. Tighten the locknuts, and then tighten the axle nut to the specified torque.

Tightening torque:

Axle nut:

117 Nm (11.7 m·kgf)

Lubricating the drive chain

EAU03006

The drive chain must be cleaned and lubricated at the intervals specified in the periodic maintenance and lubrication chart, otherwise it will quickly wear out, especially when riding in dusty or wet areas. Service the drive chain as follows.

EC000097

CAUTION:

The drive chain must be lubricated after washing the motorcycle or riding in the rain.

1. Clean the drive chain with kerosene and a small soft brush.

ECA00053

CAUTION:

To prevent damaging the O-rings, do not clean the drive chain with steam cleaners, high-pressure washers or inappropriate solvents.

2. Wipe the drive chain dry.
3. Thoroughly lubricate the drive chain with a special O-ring chain lubricant.

ECA00052

CAUTION:

Do not use engine oil or any other lubricants for the drive chain, as they may contain substances that could damage the O-rings.

PERIODIC MAINTENANCE AND MINOR REPAIR

Checking and lubricating the cables

EAU02962

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it.

Recommended lubricant:
Engine oil

EW000112

WARNING

Damage to the outer sheath may interfere with proper cable operation and will cause the inner cable to rust. Replace a damaged cable as soon as possible to prevent unsafe conditions.

Checking and lubricating the throttle grip and cable

EAU04034

The operation of the throttle grip should be checked before each ride. In addition, the cable should be lubricated or replaced at the intervals specified in the periodic maintenance chart.

Checking and lubricating the brake and shift pedals

EAU03370

The operation of the brake and shift pedals should be checked before each ride, and the pedal pivots should be lubricated if necessary.

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)

PERIODIC MAINTENANCE AND MINOR REPAIR

Checking and lubricating the brake and clutch levers

EAU03164

The operation of the brake and clutch levers should be checked before each ride, and the lever pivots should be lubricated if necessary.

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)

Checking and lubricating the sidestand

EAU03165

The operation of the sidestand should be checked before each ride, and the sidestand pivot and metal-to-metal contact surfaces should be lubricated if necessary.

WARNING

If the sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it.

EW000113

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)

Lubricating the rear suspension

EAU04282

The pivoting points of the rear suspension must be lubricated at the intervals specified in the periodic maintenance and lubrication chart.

Recommended lubricant:
Lithium-soap-based grease

PERIODIC MAINTENANCE AND MINOR REPAIR

Checking the front fork

EAU02939

The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.


To check the condition

EW000115

! WARNING

Securely support the motorcycle so that there is no danger of it falling over.

Check the inner tubes for scratches, damage and excessive oil leakage.



To check the operation

1. Place the motorcycle on a level surface and hold it in an upright position.
2. While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.

EC000098

CAUTION:

If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.

EAU00794

Checking the steering

Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.


1. Place a stand under the engine to raise the front wheel off the ground.

EW000115

! WARNING

Securely support the motorcycle so that there is no danger of it falling over.

EAU01144



Checking the wheel bearings

The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

2. Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.

PERIODIC MAINTENANCE AND MINOR REPAIR

Battery

EAU00800

This motorcycle is equipped with a sealed-type (MF) battery, which does not require any maintenance. There is no need to check the electrolyte or to add distilled water.

EC000101

CAUTION:

Never attempt to remove the battery cell seals, as this would permanently damage the battery.

EW000116

⚠ WARNING

- Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.
 - EXTERNAL: Flush with plenty of water.

- INTERNAL: Drink large quantities of water or milk and immediately call a physician.
- EYES: Flush with water for 15 minutes and seek prompt medical attention.
- Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.
- KEEP THIS AND ALL BATTERIES OUT OF THE REACH OF CHILDREN.

To charge the battery

Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the battery tends to discharge more quickly if the motorcycle is equipped with optional electrical accessories.

To store the battery


1. If the motorcycle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place.
2. If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.
3. Fully charge the battery before installation.
4. After installation, make sure that the battery leads are properly connected to the battery terminals.

PERIODIC MAINTENANCE AND MINOR REPAIR

EC000102

CAUTION:

- Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.
- To charge a sealed-type (MF) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery. If you do not have access to a sealed-type (MF) battery charger, have a Yamaha dealer charge your battery.



1. Headlight fuse
2. Signaling system fuse
3. Ignition fuse
4. Radiator fan fuse
5. Spare fuse (× 2)


EAU04246*

Replacing the fuses

The main fuse and the fuse box, which contains the fuses for the individual circuits, are located under the seat. (See page 3-11 for seat removal and installation procedures.)

If a fuse is blown, replace it as follows.

1. Turn the key to “OFF” and turn off the electrical circuit in question.
2. Remove the blown fuse, and then install a new fuse of the specified amperage.



1. Main fuse

Specified fuses:

Main fuse:	30 A
Headlight fuse:	20 A
Signaling system fuse:	15 A
Radiator fan fuse:	7.5 A
Ignition fuse:	7.5 A


EC000103

CAUTION:


Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire.

PERIODIC MAINTENANCE AND MINOR REPAIR

3. Turn the key to “ON” and turn on the electrical circuit in question to check if the device operates.
4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.



1. Headlight coupler
2. Headlight bulb cover



1. Headlight bulb holder
2. Unhook the headlight bulb holder, and then remove the defective bulb.


EAU04160

Replacing the headlight bulb

This motorcycle is equipped with a quartz bulb headlight. If the headlight bulb burns out, replace it as follows.

1. Disconnect the headlight coupler, and then remove the bulb cover.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Do not touch this area.

EW000119


EC000104

CAUTION:

Take care not to damage the following parts:

- **Headlight bulb**
Do not touch the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the luminosity of the bulb, and the bulb life will be adversely affected. Thoroughly clean off any dirt and fingerprints on the headlight bulb using a cloth moistened with alcohol or thinner.
- **Headlight lens**
 - Do not affix any type of tinted film or stickers to the headlight lens.
 - Do not use a headlight bulb of a wattage higher than specified.

4. Install the headlight bulb cover, and then connect the coupler.
5. Have a Yamaha dealer adjust the headlight beam if necessary.



1. Screw (× 2)

EAU01623

Replacing the tail/brake light bulb

1. Remove the tail/brake light lens by removing the screws.
2. Remove the defective bulb by pushing it in and turning it counter-clockwise.
3. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
4. Install the lens by installing the screws.

EC000108

CAUTION:


Do not overtighten the screws, otherwise the lens may break.

WARNING

Headlight bulbs get very hot. Therefore, keep flammable products away from a lit headlight bulb, and do not touch the bulb until it has cooled down.

3. Place a new headlight bulb into position, and then secure it with the bulb holder.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Screw

EAU03497

Replacing a turn signal light bulb

1. Remove the turn signal light lens by removing the screw.
2. Remove the defective bulb by pushing it in and turning it counter-clockwise.
3. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
4. Install the lens by installing the screw.

ECA00065

CAUTION:

Do not overtighten the screw, otherwise the lens may break.

EAU01579

Supporting the motorcycle

Since this model is not equipped with a centerstand, follow these precautions when removing the front and rear wheel or performing other maintenance requiring the motorcycle to stand upright. Check that the motorcycle is in a stable and level position before starting any maintenance. A strong wooden box can be placed under the engine for added stability.


To service the front wheel

1. Stabilize the rear of the motorcycle by using a motorcycle stand or, if an additional motorcycle stand is not available, by placing a jack under the frame in front of the rear wheel.
2. Raise the front wheel off the ground by using a motorcycle stand.

To service the rear wheel

Raise the rear wheel off the ground by using a motorcycle stand or, if a motorcycle stand is not available, by placing a jack either under each side of the frame in front of the rear wheel or under each side of the swingarm.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Speedometer cable
2. Bolt (x 2)
3. Front fender
4. Bolt (x 2)
5. Brake caliper
6. Brake hose holder

EAU03582

Front wheel


To remove the front wheel

EW000122

WARNING

- It is advisable to have a Yamaha dealer service the wheel.
- Securely support the motorcycle so that there is no danger of it falling over.

1. Disconnect the speedometer cable from the front wheel.



1. Front fender
2. Bolt (x 2)
3. Front wheel axle pinch bolt
4. Wheel axle
5. Bolt (x 2)
6. Brake caliper
7. Brake hose holder

2. Remove the front fender by removing the bolts.
3. Loosen the front wheel axle pinch bolt, then the wheel axle and the brake caliper bolts.
4. Lift the front wheel off the ground according to the procedure on page 6-39.
5. Remove the brake hose holders on each side by removing the bolts.


6. Remove the brake calipers on each side by removing the bolts.
7. Pull the wheel axle out, remove the speedometer gear unit, and then remove the wheel.

ECA00046

CAUTION:

Do not apply the brake after the brake calipers have been removed, otherwise the brake pads will be forced shut.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Speedometer gear unit
2. Slot
3. Speedometer gear unit retainer

EAU04196

To install the front wheel

1. Install the speedometer gear unit into the wheel hub so that the projections mesh with the slots.
2. Lift the wheel up between the fork legs.

NOTE:

Make sure that the slot in the speedometer gear unit fits over the retainer on the fork leg.

3. Insert the wheel axle.
4. Lower the front wheel so that it is on the ground.

5. Install the brake calipers by installing the bolts.

NOTE:

Make sure that there is enough space between the brake pads before installing the brake calipers onto the brake discs.

6. Tighten the wheel axle, then the front wheel axle pinch bolt and the brake caliper bolts to the specified torques.

Tightening torques:

Wheel axle:

65 Nm (6.5 m·kgf)


Front wheel axle pinch bolt:

20 Nm (2.0 m·kgf)

Brake caliper bolt:

40 Nm (4.0 m·kgf)

7. Install the brake hose holders by installing the bolts.
8. Connect the speedometer cable.
9. Install the front fender by installing the bolts.
10. Push down hard on the handlebar several times to check for proper fork operation.



1. Axle nut
2. Left wheel axle guide
3. Locknut
4. Drive chain slack adjusting nut
5. Wheel axle

EAU04197

Rear wheel


To remove the rear wheel

EW000122

⚠ WARNING


- It is advisable to have a Yamaha dealer service the wheel.
- Securely support the motorcycle so that there is no danger of it falling over.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Cotter pin
2. Nut
3. Bolt
4. Brake torque rod

1. Loosen the wheel axle nut, the brake torque rod nut at the brake caliper bracket, and the brake caliper bolts.
2. Lift the rear wheel off the ground according to the procedure on page 6-39.




1. Bolt (x 2)
2. Right wheel axle guide

3. Remove the axle nut and the left wheel axle guide, and then remove the brake caliper by removing the bolts.
4. Disconnect the brake torque rod from the brake caliper bracket by removing the cotter pin, the nut, and the bolt.
5. Loosen the locknut and the drive chain slack adjusting nut on both sides of the swingarm.
6. Push the wheel forward, and then remove the drive chain from the rear sprocket.

NOTE:

The drive chain does not need to be disassembled in order to remove and install the wheel.



1. Brake caliper bracket

7. Pull the wheel axle out along with the right wheel axle guide, remove the brake caliper bracket, and then remove the wheel.


CAUTION:

Do not apply the brake after the wheel has been removed together with the brake disc, otherwise the brake pads will be forced shut.

ECA00048

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03087



EAU04283

To install the rear wheel

1. Install the wheel, right wheel axle guide, and caliper bracket by inserting the wheel axle from the right-hand side.
2. Install the drive chain onto the rear sprocket, and then install the left wheel axle guide and the axle nut.
3. Install the brake caliper by installing the bolts, and then connect the brake torque rod to the brake caliper bracket by installing the bolt and nut.

NOTE:

Make sure that there is enough space between the brake pads before installing the brake caliper onto the brake disc.

4. Adjust the drive chain slack. (See page 6-29 for drive chain slack adjustment procedures.)
5. Lower the rear wheel so that it is on the ground.
6. Tighten the axle nut, the brake caliper bolts and the brake torque rod nut to the specified torques.

Tightening torques:

Axle nut:

117 Nm (11.7 m·kgf)

Brake caliper bolt:

40 Nm (4.0 m·kgf)

Brake torque rod nut:

30 Nm (3.0 m·kgf)

7. Install a new cotter pin into the brake torque rod bolt.

EWA00051

WARNING

Always use a new cotter pin for the brake torque rod bolt.

Troubleshooting

Although Yamaha motorcycles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting charts represent quick and easy procedures for checking these vital systems yourself. However, should your motorcycle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the motorcycle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU02990

Troubleshooting charts

Starting problems or poor engine performance


EW000125




WARNING

Keep away open flames and do not smoke while checking or working on the fuel system.


1. Fuel




2. Compression



3. Ignition



4. Battery




PERIODIC MAINTENANCE AND MINOR REPAIR

Engine overheating

EW000070

! WARNING

- Do not remove the radiator cap when the engine and radiator are hot. Scalding hot fluid and steam may be blown out under pressure, which could cause serious injury. Be sure to wait until the engine has cooled.
- After removing the radiator cap retaining bolt, place a thick rag, like a towel, over the radiator cap, and then slowly rotate the cap counterclockwise to the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the cap while turning it counterclockwise, and then remove the cap.



NOTE:

If coolant is not available, tap water can be temporarily used instead, provided that it is changed to the recommended coolant as soon as possible.

MOTORCYCLE CARE AND STORAGE

Care	7-1
Storage	7-4

Care

While the open design of a motorcycle reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a motorcycle. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your motorcycle looking good, extend its life and optimize its performance.

Before cleaning

1. Cover the muffler outlet with a plastic bag after the engine has cooled down.
2. Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug caps, are tightly installed.
3. Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such products onto seals, gaskets, sprockets, the drive chain and wheel axles. Always rinse the dirt and degreaser off with water.

Cleaning

ECA00010

CAUTION:

- **Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.**
- **Improper cleaning can damage windshields, cowlings, panels and other plastic parts. Use only a soft, clean cloth or sponge with mild detergent and water to clean plastic.**

MOTORCYCLE CARE AND STORAGE

- Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.
- Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swing-arm bearings, fork and brakes), electric components (couplers, connectors, instruments, switches and lights), breather hoses and vents.
- For motorcycles equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or scratching. Some cleaning compounds for plastic may leave scratches on the windshield. Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.

After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

After riding in the rain, near the sea or on salt-sprayed roads

Since sea salt or salt sprayed on roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea or on salt-sprayed roads.

NOTE: _____

Salt sprayed on roads in the winter may remain well into spring.

1. Clean the motorcycle with cold water and a mild detergent, after the engine has cooled down.

ECA00012

CAUTION: _____

Do not use warm water since it increases the corrosive action of the salt.

2. Apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces to prevent corrosion.

MOTORCYCLE CARE AND STORAGE

After cleaning

1. Dry the motorcycle with a chamois or an absorbing cloth.
2. Immediately dry the drive chain and lubricate it to prevent it from rusting.
3. Use a chrome polish to shine chrome, aluminum and stainless-steel parts, including the exhaust system. (Even the thermally induced discoloring of stainless-steel exhaust systems can be removed through polishing.)
4. To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
5. Use spray oil as a universal cleaner to remove any remaining dirt.
6. Touch up minor paint damage caused by stones, etc.
7. Wax all painted surfaces.
8. Let the motorcycle dry completely before storing or covering it.

EWA00001

WARNING

- **Make sure that there is no oil or wax on the brakes or tires. If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent.**
- **Before operating the motorcycle test its braking performance and cornering behavior.**

ECA00013

CAUTION:

- **Apply spray oil and wax sparingly and make sure to wipe off any excess.**
- **Never apply oil or wax to any rubber and plastic parts, but treat them with a suitable care product.**
- **Avoid using abrasive polishing compounds as they will wear away the paint.**

NOTE:

Consult a Yamaha dealer for advice on what products to use.

MOTORCYCLE CARE AND STORAGE

Storage

Short-term

Always store your motorcycle in a cool, dry place and, if necessary, protect it against dust with a porous cover.

ECA00014

CAUTION:

- **Storing the motorcycle in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.**
- **To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.**

Long-term

Before storing your motorcycle for several months:

1. Follow all the instructions in the “Care” section of this chapter.
2. For motorcycles equipped with a fuel cock that has an “OFF” position: Turn the fuel cock lever to “OFF”.
3. Drain the carburetor float chamber by loosening the drain bolt; this will prevent fuel deposits from building up. Pour the drained fuel into the fuel tank.
4. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
5. Perform the following steps to protect the cylinders, piston rings, etc. from corrosion.

- a. Remove the spark plug caps and spark plugs.
- b. Pour a teaspoonful of engine oil into each spark plug bore.
- c. Install the spark plug caps onto the spark plugs, and then place the spark plugs on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
- d. Turn the engine over several times with the starter. (This will coat the cylinder walls with oil.)
- e. Remove the spark plug caps from the spark plugs, and then install the spark plugs and the spark plug caps.

EWA00003

WARNING

To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.

MOTORCYCLE CARE AND STORAGE

6. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the sidestand/centerstand.
7. Check and, if necessary, correct the tire air pressure, and then lift the motorcycle so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
8. Cover the muffler outlet with a plastic bag to prevent moisture from entering it.
9. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place [less than 0 °C or more than 30 °C. For more information on storing the battery, see page 6-35.

NOTE: _____
Make any necessary repairs before
storing the motorcycle.


Specifications 8-1
Conversion table 8-5

Specifications

Model	YZF600R
Dimensions	
Overall length	2,145 mm (except for F, E, I, GR)
	2,060 mm (for F, E, I, GR)
Overall width	725 mm
Overall height	1,190 mm
Seat height	805 mm
Wheelbase	1,415 mm
Ground clearance	135 mm
Minimum turning radius	3,200 mm
Basic weight (with oil and full fuel tank)	212 kg (except for A, CH, S)
	214 kg (for A, CH, S)
Engine	
Engine type	Liquid-cooled 4-stroke, DOHC
Cylinder arrangement	Forward-inclined parallel 4-cylinder
Displacement	599 cm ³
Bore × stroke	62.0 × 49.6 mm
Compression ratio	12:1
Starting system	Electric starter
Lubrication system	Wet sump

Engine oil

Type



Recommended engine oil classification

API Service SE, SF, SG or higher

CAUTION:

Be sure to use motor oils that do not contain anti-friction modifiers. Passenger car motor oils (often labeled “ENERGY CONSERVING II”) contain anti-friction additives which will cause clutch and/or starter clutch slippage, resulting in reduced component life and poor engine performance.

Quantity

Without oil filter cartridge replacement	2.6 L
With oil filter cartridge replacement	2.9 L
Total amount (dry engine)	3.5 L

SPECIFICATIONS

Cooling system capacity (total amount)

1.95 L

Air filter

Wet element

Fuel

Type

REGULAR UNLEADED
GASOLINE ONLY

Fuel tank capacity

19 L

Reserve amount

3.1 L

Carburetor

Manufacturer

KEIHIN

Model × quantity

CVKD36 × 4

Spark plug

Manufacturer/model

NGK / CR9E or
DENSO / U27ESR-N

Gap

0.7–0.8 mm

Clutch type

Wet, multiple-disc

Transmission

Primary reduction system

Spur gear

Primary reduction ratio

1.708

Secondary reduction system

Chain drive

Secondary reduction ratio

3.133

Number of drive chain sprocket teeth (front/rear)

15/47

Transmission type

Constant-mesh 6-speed

Operation

Left foot

Gear ratio

1st 2.846

2nd 1.947

3rd 1.545

4th 1.333

5th 1.190

6th 1.074

Chassis

Frame type

Diamond

Caster angle

25°

Trail

97 mm

Tires

Front

Type

Tubeless tire

Size

120/60 ZR17 (55W)

120/60 ZR17 M/C (55W)

Manufacturer/model

Bridgestone / BT57F

Dunlop / D204F

Metzeler / MEZ1 FRONT

Michelin / MACADAM 90X

SPECIFICATIONS

Rear

Type	Tubeless tire
Size	160/60 ZR17 (69W) 160/60 ZR17 M/C (69W)
Manufacturer/model	Bridgestone / BT57 Dunlop / D204 Metzeler / MEZ1 Michelin / MACADAM 90X
Maximum load*	180 kg (except for A, CH, S) 178 kg (for A, CH, S)
Tire air pressure (measured on cold tires)	
Up to 90 kg*	
Front	225 kPa (2.25 kgf/cm ² , 2.25 bar)
Rear	250 kPa (2.50 kgf/cm ² , 2.50 bar)
90 kg–maximum*	
Front	250 kPa (2.50 kgf/cm ² , 2.50 bar)
Rear	290 kPa (2.90 kgf/cm ² , 2.90 bar)
High-speed riding	
Front	250 kPa (2.50 kgf/cm ² , 2.50 bar)
Rear	290 kPa (2.90 kgf/cm ² , 2.90 bar)

* Total weight of rider, passenger, cargo and accessories

Wheels

Front		
Type		Cast wheel
Size		17 × MT 3.50 17 M/C × MT 3.50
Rear		
Type		Cast wheel
Size		17 × MT 5.00 17 M/C × MT 5.00

Brakes

Front		
Type		Dual disc brake
Operation		Right hand
Fluid		DOT 4
Rear		
Type		Single disc brake
Operation		Right foot
Fluid		DOT 4

Suspension

Front	Telescopic fork
Rear	Swingarm (link suspension)

Spring/shock absorber

Front	Coil spring / oil damper
Rear	Coil spring / gas-oil damper

Wheel travel

Front	130 mm
Rear	120 mm

Electrical system

Ignition system	T.C.I. (digital)
Charging system	
Type	A.C. magneto
Standard output	14 V, 18.5 A @ 5,000 r/min

Battery

Model	YTX12-BS
Voltage, capacity	12 V, 10 Ah

Headlight type

Quartz bulb (halogen)

Bulb voltage, wattage × quantity

Headlight	12 V, 60/55 W × 1
Tail/brake light	12 V, 5/21 W × 1
Turn signal light	12 V, 21 W × 4
Auxiliary light	12 V, 4 W × 1
Meter lighting	12 V, 1.7 W × 4
Neutral indicator light	12 V, 3.4 W × 1
High beam indicator light	12 V, 3.4 W × 1
Oil level warning light	12 V, 3.4 W × 1
Turn signal indicator light	12 V, 3.4 W × 1
Fuel level warning light	12 V, 3.4 W × 1

Fuses

Main fuse	30 A
Headlight fuse	20 A
Signaling system fuse	15 A
Radiator fan fuse	7.5 A
Ignition fuse	7.5 A

SPECIFICATIONS

EAU03941

Conversion table

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit values to IMPERIAL unit values.

Example:

METRIC VALUE	CONVERSION FACTOR		IMPERIAL VALUE
2 mm	× 0.03937	=	0.08 in

Conversion table


METRIC SYSTEM TO IMPERIAL SYSTEM			
	Metric unit	Conversion factor	Imperial unit
Torque	m·kgf	× 7.233	ft·lb
	m·kgf	× 86.794	in·lb
	cm·kgf	× 0.0723	ft·lb
	cm·kgf	× 0.8679	in·lb
Weight	kg	× 2.205	lb
	g	× 0.03527	oz
Speed	km/h	× 0.6214	mi/h
Distance	km	× 0.6214	mi
	m	× 3.281	ft
	m	× 1.094	yd
	cm	× 0.3937	in
	mm	× 0.03937	in
Volume, Capacity	cc (cm ³)	× 0.03527	oz (IMP liq.)
	cc (cm ³)	× 0.06102	cu-in
	L (liter)	× 0.8799	qt (IMP liq.)
	L (liter)	× 0.2199	gal (IMP liq.)
Miscellaneous	kgf/mm	× 55.997	lb/in
	kgf/cm ²	× 14.2234	psi (lb/in ²)
	°C	× 1.8 + 32	°F

Identification numbers	9-1
Key identification number	9-1
Vehicle identification number	9-1
Model label	9-2

Identification numbers

Record the key identification number, vehicle identification number and model label information in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.

EAU02944



1. Key identification number

1. KEY IDENTIFICATION NUMBER:

2. VEHICLE IDENTIFICATION NUMBER:


3. MODEL LABEL INFORMATION:

EAU01041

Key identification number

The key identification number is stamped into the key tag. Record this number in the space provided and use it for reference when ordering a new key.

EAU01043




1. Vehicle identification number

Vehicle identification number

The vehicle identification number is stamped into the steering head pipe. Record this number in the space provided.

NOTE:

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your area.



1. Model label

EAU01050

Model label

The model label is affixed to the frame under the seat. (See page 3-11 for seat removal and installation procedures.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

INDEX

A

- Air filter element, cleaning6-17
- Air intake duct6-19
- Air vent hose, checking6-18
- Anti-theft alarm3-5

B

- Battery6-35
- Brake and clutch levers, checking and lubricating6-32
- Brake and shift pedals, checking and lubricating6-31
- Brake fluid, changing6-28
- Brake fluid level, checking6-27
- Brake lever3-7
- Brake light switch (rear), adjusting6-26
- Brake pads, checking6-27
- Brake pedal3-8
- Brake pedal position, adjusting6-25

C

- Cables, checking and lubricating6-31
- Carburetors, adjusting6-19
- Care7-1
- Clutch lever3-7
- Clutch lever free play, adjusting6-25
- Conversion table8-5
- Coolant6-13
 - Changing6-14
 - Checking6-13
- Coolant temperature gauge3-5
- Cowlings, removing and installing6-5

D

- Dimmer switch3-5
- Drive chain, lubricating6-30
- Drive chain slack6-29
 - Adjusting6-29
 - Checking6-29

E

- Engine break-in5-5
- Engine oil and oil filter cartridge6-10
- Engine stop switch3-6

F

- Front and rear suspension settings3-17
- Front fork, adjusting3-13
- Front fork, checking6-33
- Fuel3-9
- Fuel consumption, tips for reducing5-4
- Fuel level warning light3-3
- Fuel tank breather hose (Germany only)3-10
- Fuel tank cap3-8
- Fuses, replacing6-36

H

- Handlebar switches3-5
- Headlight bulb, replacing6-37
- Helmet holder3-12
- High beam indicator light3-3
- Horn switch3-6

I

- Identification numbers9-1
- Idling speed, adjusting6-19
- Ignition circuit cut-off system3-19
- Indicator and warning lights3-2

K

- Key identification number9-1

L

- Light switch3-6
- Luggage strap holders3-18

M

- Main switch/steering lock3-1
- Model label9-2

N

- Neutral indicator light3-2

O

- Oil level warning light3-2

P

- Parking5-6
- Part locations2-1
- Pass switch3-5
- Periodic maintenance and lubrication chart6-2
- Pre-operation check list4-1

S

- Safety information1-1
- Seat3-11
- Self-diagnosis device3-4

Shifting	5-3
Shift pedal	3-7
Shift points (for Switzerland only).....	5-4
Shock absorber assembly, adjusting	3-15
Sidestand	3-18
Sidestand, checking and lubricating.....	6-32
Spark plugs, checking	6-8
Specifications	8-1
Speedometer unit	3-3
Starter (choke) lever	3-11
Starting a warm engine.....	5-3
Starting the engine	5-1
Start switch.....	3-6
Steering, checking.....	6-33
Storage.....	7-4
Storage compartment	3-12
Supporting the motorcycle	6-39
Suspension (rear), lubricating	6-32

T

Tachometer	3-4
Tail/brake light bulb, replacing	6-38
Throttle cable free play, adjusting	6-20
Throttle grip and cable, checking and lubricating.....	6-31
Tires	6-21
Tool kit.....	6-1
Troubleshooting.....	6-43
Troubleshooting charts	6-44
Turn signal indicator light.....	3-3
Turn signal light bulb, replacing	6-39
Turn signal switch.....	3-6

V

Valve clearance, adjusting	6-20
Vehicle identification number.....	9-1

W

Wheel bearings, checking	6-34
Wheel (front)	6-40
Installing.....	6-41
Removing	6-40
Wheel (rear).....	6-41
Installing	6-43
Removing	6-41
Wheels.....	6-24



PRINTED ON RECYCLED PAPER

PRINTED IN JAPAN
2001.6-0.3×1 CR
(E)